

# WIRING DIAGRAM FOR H-S-S

Directions: Tie white & green wires together (Ground) and solder to volume pot. Take orange wires (hot) and connect to switch where noted by arrows.

Note: All Lead wires are on the same side as the high "E" lead string.

250K pots recommended for better tone.  
.022 mfd cap recommended.

